

PMIC

Note: This USB is only for power and could be used to connect with a secondary small CPU such as STM32

