




uSD Card



SATA



eMMC



U7B eMMC5		
A4	NC1	NC68
A6	NC2	NC69
A9	NC3	NC70
A11	NC4	NC71
B2	NC5	NC72
B13	NC6	NC73
D1	NC7	NC74
D14	NC8	NC75
H1		NC76
H2		NC77
H7		NC78
H8	NC12	NC79
H9	NC13	NC80
H10	NC14	NC81
H11	NC15	NC82
H12	NC16	NC83
H13	NC17	NC84
H14	NC18	NC85
J1	NC19	NC86
J7	NC20	NC87
J8	NC21	NC88
J9	NC22	NC89
J10	NC23	NC90
J11	NC24	NC91
J12	NC25	NC92
J13	NC26	NC93
J14	NC27	NC94
K1		NC95
K3		NC96
K5		NC97
K7		NC98
K8	NC31	NC99
K9	NC32	NC100
K10	NC33	NC101
K11	NC34	NC102
K12	NC35	NC103
K13	NC36	NC104
K14	NC37	NC105
L1	NC38	NC106
L2	NC39	NC107
L3	NC40	NC108
L4	NC41	NC109
L12	NC43	NC110
L13	NC44	NC111
L14	NC45	NC112
M1	NC46	NC113
M2	NC47	NC114
M3	NC48	NC115
M12	NC49	NC116
M13	NC50	NC117
M14	NC51	NC118
M5	RFU3(NC52)	NC119
M8	RFU4(NC53)	NC120
M9	RFU5(NC54)	NC121
M10	RFU6(NC55)	NC122
N1	NC56	NC123
N2	NC57	NC124
N3	NC58	NC125
N10	RFU7(NC59)	NC126
N12	NC60	NC127
N13	NC61	NC128
N14	NC62	NC129
P1	NC63	NC130
P2	NC64	NC131
P3	RFU8(NC65)	NC132
P10	RFU9(NC66)	NC133
P12	NC67	NC134
		NC135
		NC136